

DIN EN ISO 16000-12:2008-08 (E)

Indoor air - Part 12: Sampling strategy for polychlorinated biphenyls (PCBs), polychlorinated dibenzo-p-dioxins (PCDDs), polychlorinated dibenzofurans (PCDFs) and polycyclic aromatic hydrocarbons (PAHs) (ISO 16000-12:2008)

Contents

Page

Foreword.....	3
Introduction	4
1 Scope	5
2 Normative references	5
3 Sources and incidence of PCBs, PCDDs/PCDFs and PAHs	5
4 Measurement procedure	7
5 Measurement planning.....	8
Annex A (informative) Structures, toxicity and calculation of toxic equivalents	13
Annex B (informative) Procedure for investigating possible sources of indoor PCB pollution with a view to possible renovation.....	17
Annex C (informative) Indoor investigations for PCDDs/PCDFs after fires	19
Bibliography	20