

DIN EN 1995-1-2: 2010-12(E)

Eurocode_5: Design of timber structures_ - Part_1-2: General_ - Structural fire design (includes Corrigendum AC:2009)

Contents

Foreword to EN 1995-1-2:2004 + AC:2009	4
Background of the Eurocode programme	4
Status and field of application of Eurocodes	5
National Standards implementing Eurocodes	5
Links between Eurocodes and harmonised technical specifications (ENs and ETAs) for products	6
Additional information specific to EN 1995-1-2	6
National annex for EN 1995-1-2	7
Section 1 General	9
1.1 Scope	9
1.1.1 Scope of Eurocode 5	9
1.1.2 Scope of EN 1995-1-2	9
1.2 Normative references	10
1.3 Assumptions	10
1.4 Distinction between principles and application rules	10
1.5 Terms and definitions	11
1.6 Symbols	11
Section 2 Basis of design	14
2.1 Requirements	14
2.1.1 Basic requirements	14
2.1.2 Nominal fire exposure	14
2.1.3 Parametric fire exposure	14
2.2 Actions	15
2.3 Design values of material properties and resistances	15
2.4 Verification methods	16
2.4.1 General	16
2.4.2 Member analysis	17
2.4.3 Analysis of parts of the structure	18
2.4.4 Global structural analysis	19
Section 3 Material properties	20
3.1 General	20
3.2 Mechanical properties	20
3.3 Thermal properties	20
3.4 Charring depth	20
3.4.1 General	20
3.4.2 Surfaces unprotected throughout the time of fire exposure	21
3.4.3 Surfaces of beams and columns initially protected from fire exposure	23
3.4.3.1 General	23
3.4.3.2 Charring rates	26
3.4.3.3 Start of charring	27
3.4.3.4 Failure times of fire protective claddings	28
3.5 Adhesives	29
Section 4 Design procedures for mechanical resistance	30
4.1 General	30
4.2 Simplified rules for determining cross-sectional properties	30
4.2.1 General	30
4.2.2 Reduced cross-section method	30
4.2.3 Reduced properties method	31
4.3 Simplified rules for analysis of structural members and components	32
4.3.1 General	32
4.3.2 Beams	32
4.3.3 Columns	33
4.3.4 Mechanically jointed members	33
4.3.5 Bracings	34
4.4 Advanced calculation methods	34
Section 5 Design procedures for wall and floor assemblies	35

5.1	General	35
5.2	Analysis of load-bearing function	35
5.3	Analysis of separating function	35
Section 6	Connections	36
6.1	General	36
6.2	Connections with side members of wood	36
6.2.1	Simplified rules	36
6.2.1.1	Unprotected connections	36
6.2.1.2	Protected connections	37
6.2.1.3	Additional rules for connections with internal steel plates	38
6.2.2	Reduced load method	39
6.2.2.1	Unprotected connections	39
6.2.2.2	Protected connections	41
6.3	Connections with external steel plates	41
6.3.1	Unprotected connections	41
6.3.2	Protected connections	41
6.4	Simplified rules for axially loaded screws	41
Section 7	Detailing	43
7.1	Walls and floors	43
7.1.1	Dimensions and spacings	43
7.1.2	Detailing of panel connections	43
7.1.3	Insulation	43
7.2	Other elements	43
Annex A (informative)	Parametric fire exposure	45
A1	General	45
A2	Charring rates and charring depths	45
A3	Mechanical resistance of members in edgewise bending	47
Annex B (informative)	Advanced calculation methods	48
B1	General	48
B2	Thermal properties	48
B3	Mechanical properties	50
Annex C (informative)	Load-bearing floor joists and wall studs in assemblies whose cavities are completely filled with insulation	52
C1	General	52
C2	Residual cross-section	52
C2.1	Charring rates	52
C2.2	Start of charring	54
C2.3	Failure times of panels	54
C3	Reduction of strength and stiffness parameters	56
Annex D (informative)	Charring of members in wall and floor assemblies with void cavities	58
D1	General	58
D2	Charring rates	58
D3	Start of charring	58
D4	Failure times of panels	58
Annex E (informative)	Analysis of the separating function of wall and floor assemblies	60
E1	General	60
E2	Simplified method for the analysis of insulation	60
E2.1	General	60
E2.2	Basic insulation values	61
E2.3	Position coefficients	62
E2.4	Effect of joints	62
Annex F (informative)	Guidance for users of this Eurocode Part	68